

INSTRUCTIONS FOR RE-CABLING HURRICANE CANOES

1. First you pull foot pedals back to get as much slack on the cables as possible, pull slack out from the back by the rudder shaft.
2. Cut the old cable at the rudder end as close to the plastic tiller arm as possible.
3. Take the leader thread from the new cable and tie it to one strand of the newly cut end of the old cable. Spectra is slippery so first tie a square knot, then add a half hitch to each side of the square knot.
4. Give the knot a tug to see if the knot slips. It's easier to fix now than if the knot lets go halfway through the canoe.
5. Then pull the new cord through.
6. Once out, cut the old one free and untie the old knot holding the old cord to the foot pedal. You can cut this too.
7. Then you thread the new cord through the rubber hose and then the hole in the foot pedal.



8. Thread the leader through the white loop.



9. Open up the loop on the black cord using the leader. Put the knob on the white loop through the black loop.



10. Pull the knot tight to secure the cable.



11. Repeat process for the other cable.

12. Then twist the cables many times if you need them to be shorter.

Call if you have questions.

Foti Bros. Hawaii LLC

521 Ala Moana Blvd. #111

Honolulu, Hi. 96813

ph 808 524-6677, fax 808 524-6678

www.fotibros.com